

SIMPLE TO OPERATE

Complete turnkey water system that allows you to recycle all of your water.

- · Only minutes of daily maintenance needed.
- Removes over 95% of the solids from your slurry water
- Easily installs in a 5' x 10' space in your shop

EASY TO INSTALL

- Ships ready to run for a hassle free installation
- Operational in as little as two hours

EFFORTLESS TO MAINTAIN

- Perform a daily purge in the morning for 3-5 seconds
- Check polymer level and fill as necessary (average system uses 1 gallon every 1-2 months)
- Check the sludge skid bag and discard as needed (typically every 4000 produced sq feet of stone)
- · Replace the water in the system annually for best results





WHAT DO I NEED?

- A slurry collection pit (recommended size of 500-1000 gallons)
- 5' x 10' of floor space
- A 3000 pound minimum forklift
- 1/4 or 3/8 inch airline with a minimum air supply of 80 psi and 3 cfm of air
- 3 phase Power disconnect nearby with 30 amp breaker (208,230,460 volts supported)
- Return plumbing line from the WaterBear (2" FPT) to your equipment
- Fresh water for any waterjet intensifier

WHAT DOES IT COST TO OPERATE?

- Less than \$1.00 per kitchen for supplies and operating costs
- Less than 15 minutes of proactive maintenance per week.

The WaterBear protects your business by ensuring compliance with all water ordinances and requirements allowing you to focus on your production and not your water. Any employee can easily learn to operate and maintain this system. Through the latest technology, the WaterBear continuously treats your water and supplies all the clean water flow necessary to operate a small to medium size countertop facility.



Phone: 320-529-4035 info@fullcirclewater.com

Service Department 320-407-8318
Sales Department 320-529-4035 ext 2
Accounting/Billing Department 320-407-8319
Shipping/Receiving Department 320-407-8319
Fax Line 320-529-4036

BUILT IN MINNESOTA, THE LAND OF 10,000 LAKES