

Weha Donkey Inline Pads					
GQ PN	Description	Diameter	PSI	BAR	Belt Speed
368608	WEHA DONKEY INLINE QRS PAD 5" STEP 0	5"	43.5	3	48-100"
368609	WEHA DONKEY INLINE QRS PAD 5" STEP 1	5"	36	2.5	48-100"
368610	WEHA DONKEY INLINE QRS PAD 5" STEP 2	5"	36	2.5	48-100"
368611	WEHA DONKEY INLINE QRS PAD 5" STEP 3	5"	36	2.5	48-100"
368617	WEHA DONKEY INLINE QRS PAD 6" STEP 0	6"	43.5	3	48-100"
368618	WEHA DONKEY INLINE QRS PAD 6" STEP 1	6"	36	2.5	48-100"
368619	WEHA DONKEY INLINE QRS PAD 6" STEP 2	6"	36	2.5	48-100"
368620	WEHA DONKEY INLINE QRS PAD 6" STEP 3	6"	36	2.5	48-100"
The information above represents a starting point for tool use. Adjust these parameters as necessary for your specific application, including material, machine, etc.					