



## Vapor Shark® Instructions For Use

Fig. 1



Place unit on a firm, stable surface in a relatively high location. Unlatch case & pull out membrane rack.

Fig. 2



Remove membrane from outer plastic shipping bag. Unfold membrane & place into the rack. Wash hands after handling membranes.

Fig. 3



Adjust air inlet by rotating dial clockwise to loosen lever. Move the lever up & down to adjust air flow.

Fig. 4



Plug the Vapor Shark into outlet.

Fig. 5



Click the On/Off button into the On position. When not in use, preserve membrane life by closing all inlet openings.

This unit delivers odor-neutralizing dry vapor for permanent odor control. It does not produce ozone, hydroxyl, or any added moisture. This product is safe to use in occupied spaces. For use instructions, safety guidelines, and membrane best practices, please visit us online.

FOR USE & OPERATION MANUAL VISIT  
**WWW.VAPORTEK.COM**

**For maximum performance, replace membranes after 270 hours of use. Do not allow membranes to contact finished surfaces; damage from oils may occur.**

IMPEDANCE-PROTECTED/  
PROTECTION PAR IMPÉDANCE

DO NOT IMMERSE IN WATER



110/120 Volts  
60 Hertz  
30 Watts  
35-7028B